MX Interchangeability Chart

ETFE

Description	Front Casing	Mouth Ring	Impeller Imp Pins	O-ring	Magnet Capsule Assembly	Shaft	Thrust Collar	Rear Casing	Motor Adaptor	Drive Magnet	Base Plate
Item Number	1	2	Impeller - 3 Imp. Pins - 17*	4	5 ~ 6	7	8	9	13	10	12
MX-F250											
MX-F400											
MX-F401											
MX-F402											
MX-F403											

* Impeller pins required on MX-F402 and MX-F403 only.

Five Boynton Road Hopping Brook Park Holliston, MA 01746-1446 U.S.A.
Tel: 508-429-1440
Web: www.iwakiamerica.com
Fax: 508-429-1386